

LITTLE JACK



遊び方

ジャックを、豆の木に従い、操作レバーにより上下左右に自由に動かし、3つの門の1つに導き、途中昆虫剤を手にするにより、一定時間毛虫に対して反撃できる。ただし、その時の動きは、左右のみで上下に動くことはできない。一匹退治することにより、100点、300点、500点、800点と、ポイントが増える。ジャックが城に到着すると、Aバターの1回目は終了、画面右下のジャックの家に宝物を持ち帰る。

HOW TO PLAY

Avoiding any obstacles, you must make Jack climb up a big tree to obtain Gold, Hen, and Harp from the castle above clouds and bring them back to his house. By operating the control lever, you can move Jack up and down, right and left and lead him to one of three gates.

On his way to the gates, he can counterattack creepers at certain times by using the insecticide.

But then he can move only right and left but up and down.

When Jack kills creepers, points increase as follows.

1 creeper-100points 2 creepers-300points
3 creepers-500points 4 creepers-800points

When the wave of the castle, first wave of the pattern is over, make him come back with treasures.



株式会社 ショウエイ

〒183 東京都府中市大井町1-3-9
TEL 0423-65-2654(代) TELEX 2832548

Shoei CO., LTD.

4-3-9 Toincho Fuchu Shi, Tokyo JAPAN
TELEPHONE 0423-65-2654 TELEX 2832548 SHOEI J